



GLIND

Motorhome / Marine Hot Water System

Fitting and Operating Notes for the Glind Motorhome / Marine Hot Water System

Fitting Notes

- Insert Glind heat exchanger into coolant line and secure.
- Plumb fresh water line from fresh water supply to pump, then to heat exchanger, then to taps or shower rose.
- Ensure no leaks, clamp hoses firmly in place, ensure no rubbing or crimped hoses.
- Mercruiser owners can obtain hot water take off kits from their authorized Mercury Dealer.
- Coolant ports in many inboard engines are bunged off, however facility is there for take off and return points to access coolant water.
- Usually coolant is accessed at the thermostathousing and returned to the waterpump. If there are bungs available, BSPx 5/8" male hose tails should be used to access this coolant

Operating Notes

- Hot water obtained depends on the volume and temperature of coolant flow
- Start engine. Some engines will only need to idle for a few minutes to reach operating temperature. Others will need to lift revs to reach desired temperature.
- Turn on switch and enjoy.

Sketch of how it works

